



RX Arms Benelli M4 Charging Handle **Installation Guide**

Installation Instructions:

It is a straight forward installation process for our Benelli M4 charge handle variants. This guide covers our Titanium Variant, and also our 7075-T6 Variants.

Our charging handle is designed to lock into place in the Detent Hole that is on the charge handle pin. As such, it can also be tougher to remove straight out as designed. If you have a brand new Benelli M4 or clone, it is suggested to put a dab of oil on the charging handle detent holes before installing it for the first time. The detent in the M4 can have burrs or rough metal that will wear over time from inserting and removing the charging handle. But initially, can be a source of friction when trying to remove the charging handle.

We recommend taking the bolt out of the firearm, and performing the initial installation. Sometimes the handle can be difficult to remove on the first insert, so it is recommended to have the bolt removed from the gun during the initial installation.

Installation/Removal Steps:

1. Remove OEM charge handle from the bolt by rotating the OEM charge handle, and pulling out.
2. Remove the bolt from the gun, for initial installation, per note above.
3. Insert the RX Arms charge handle into the bolt, orientated with the “Detent Hole” on the charge handle pin facing toward the muzzle, so the detent in the M4 Bolt engages the detent hole on the charge handle pin.
4. Remove by pulling straight out.
5. Install bolt back into the firearm.
6. Insert the charge handle again, orientated with the “detent hole” on the charge handle pin facing toward the muzzle, so the detent engages the detent hole on the charge handle pin.
7. For removal, remove pulling straight out away from the gun.

If you have additional questions, you can reach us at rx@rxarms.com, additional product details are on our website at <https://rxarms.com>